



# Resistive Table for Electric Gage Senders

## Pressure & Fuel Senders

ESP / ES2P / ESF / ES2F

<u>Resistance:</u>	<u>Pressure:</u>
240Ω	0 PSI
153Ω	25 PSI
103Ω	50 PSI
67Ω	75 PSI
33Ω	100 PSI



[www.murcal.com](http://www.murcal.com)

41343 12th Street West, Palmdale, CA 93551 (661) 272-4700 [sales@murcal.com](mailto:sales@murcal.com)